

Lithium-Ion Battery Charge Control Monolithic IC MM1532

Outline

This IC is a lithium-ion battery charge control IC. It is a one-chip charge control IC where the protection circuit incorporates constant-current/constant-voltage charge and precharge, and battery temperature detection functions. It was developed by eliminating the timer function from MM1475 (charge control IC) for providing in the small package and by changing the SW function from MM1485.

Features

1. Output voltage ($T_a = 0 \sim +50^\circ\text{C}$) $4.200 \pm 30\text{mV}$
2. Current consumption 1 1.5mA typ.
 - Precharge function
 - Adaptor (primary side) abnormality detection function
3. Battery temperature detection function

Package

TSOP-16A


Application

Lithium-ion battery charge control

Absolute Maximum Ratings ($T_a=25^\circ\text{C}$)

Item	Symbol	Ratings	Unit
Storage temperature	T _{STG}	-40~+125	°C
Operating temperature	T _{OPR}	-20~+70	°C
Power supply voltage	V _{CCMAX}	-0.3~+15	V
Allowable loss	P _D	250	mW
SW2 Input voltage	V _{SW2}	-0.3~V _{CC} +0.3	V


Block Diagram



SW1 and SW2 Specifications

SW1	SW2	Charge	Current Limit
L	H	ON	Controlled by the adaptor (current limit 1:450mV)
H	H	ON	Controlled by the adaptor (current limit 1:450mV)
L	L	OFF	
H	L	ON	Controlled by the IC (current limit 2:25mV)

Pin Assignment

















1	SW1	9	BAT
2	SW2	10	CFB
3	V _{REF}	11	CNT
4	GND	12	CS
5	ADJ	13	V _{CC}
6	CDO	14	V _{OUT2}
7	T _{OUT}	15	V _{OUT1}
8	T _{DET}	16	V _{DET-TD}

Pin Description

Pin No.	Pin Name	I/O	Function
1	SW1	Input	Charging control switching pin. Switches charging ON/OFF and charging current by combinations of SW1 and SW2 L and H.
2	SW2	Input	
3	V _{REF}	Output	Reference power supply output pin. Outputs 1.2V typ. reference voltage.
4	GND	Input	GND pin.
5	ADJ	Input	Pre-charge current adjustment pin. Pin voltage is set at 100mV typ. Pre-charge current can be adjusted by adjusting the pin voltage with an external resistor, etc. Pre-charge current is controlled by comparing the ADJ pin voltage and voltage drop value of 12dB between Vcc-CS.
6	CDO	Output	Current detection output pin. Outputs current difference value of 18dB between Vcc-CS.
7	TOUT	Output	Temperature detection output pin. Normal temperature: Output Tr OFF High temperature detection: Output Tr ON
8	T _{DET}	Input	Temperature detection input pin. Use external resistor and thermistor to apply resistance-divided potential from reference voltage.
9	BAT	Input	Battery voltage input pin. Detects battery voltage and controls charging.
10	CFB	Input	Constant-current control phase compensation pin. Connect an external capacitor (around 100pF) between CFB and CNT to perform phase compensation for improved oscillation.
11	CNT	Output	Charging control output pin. Controls external PNP-Tr base and performs constant-current, constant-voltage charging.
12	CS	Input	Current detection pin. Current is detected by voltage drop at external resistor between Vcc-CS and charging current is controlled.
13	Vcc	Input	Power supply input pin.
14	V _{OUT2}	Output	Adaptor unplugged detection output pin. Vcc low voltage input: Output Tr OFF Vcc recommended operating voltage: Output Tr ON
15	V _{OUT1}	Output	Oversupply detection output pin. Vcc oversupply input: Output Tr OFF Vcc recommended operating voltage: Output Tr ON
16	V _{DET-TD}	Input	Oversupply detection delay time setting pin. Delay time can be set by connecting an external capacitor.

Pin Description

The following values are typical

Pin No.	Pin name	Internal equivalent circuit diagram	Pin No.	Pin name	Internal equivalent circuit diagram
1	SW1		9	BAT	
2	SW2		10	CFB	
3	VREF		11	CNT	
5	ADJ		12	CS	
6	CDO		14	VOUT2	
7	TOUT		15	VOUT1	
8	TDET		16	VDET-TD	


Electrical Characteristics (Except where otherwise indicated $T_a=25^\circ\text{C}$, $V_{CC}=5\text{V}$)

Item	Symbol	Conditions	Measurement pin	Min.	Typ.	Max.	Unit
Consumption current 1	I_{CC1}	$V_{SW1}=1.2$, $V_{SW2}=0\text{V}$	13		1.5	2.3	mA
Consumption current 2	I_{CC2}	$V_{SW1}=0$, $V_{SW2}=5\text{V}$	13		3.5	5.3	mA
Reference voltage	V_{REF}		3		1.207		V
ADP detection voltage L	V_{ADPL}	$V_{CC} : H \rightarrow L$	14	2.70	2.80	2.90	V
ADP detection voltage L hysteresis voltage width	V_{ADPLW}		14	50	100	150	mV
ADP detection voltage H	V_{ADPH}	$V_{CC} : L \rightarrow H$	15	5.8	6.0	6.2	V
ADP detection voltage H hysteresis voltage width	V_{ADPHW}		15	50	100	150	mV
BAT pin leak current	I_{BAT}		9			1	μA
BAT pin output voltage	V_{BAT}	$T_a=0\text{~}\sim\text{~}+50^\circ\text{C}$	9	4.170	4.200	4.230	V
CNT pin output voltage	V_{CNT}	$I_{CNT}=20\text{mA}$	11			0.5	V
SW1 pin input current	I_{SW1}		1	40	60	80	μA
SW1 pin input voltage H	V_{SW1H}		1	0.6		1.20	V
SW1 pin input voltage L	V_{SW1L}		1			0.25	V
SW2 pin input current	I_{SW2}		2	6	12	18	μA
SW2 pin input voltage H	V_{SW2H}		2	2		V_{CC}	V
SW2 pin input voltage L	V_{SW2L}		2			0.25	V
Current limit 1	V_{L1}	Quick charge	12,13	0.35	0.45	0.55	V
Current limit 2	V_{L2}	Pre-charge	12,13	20	25	30	mV
Current detection amp gain	G_I		6	17.5	18.0	18.5	dB
Current detection amp output offset voltage	V_{OFF}		6	-4.5	0	4.5	mV
Current detection amp output current outflow	I_{CDO}		6	0.5	1.0		mA
V_{OUT1} pin output voltage	V_{OUT1}	$I_{OUT1}=0.12\text{mA}$	15		0.2	0.4	V
V_{OUT2} pin output voltage	V_{OUT2}	$I_{OUT2}=0.12\text{mA}$	14		0.2	0.4	V
Battery temperature detection voltage	V_{TDET}	$V_{TDET} : H \rightarrow L$	8	0.390	0.413	0.435	V
Battery temperature detection voltage hysteresis voltage width	V_{TDETW}		8	30	60	90	mV
T_{OUT} pin output voltage	V_{TOUT}	$I_{TOUT}=0.12\text{mA}$	7		0.2	0.4	V
T_{DET} input bias current	I_T		8		30	150	nA

* Current limits 1 and 2 are prescribed by the amount of current detection resistor voltage drop.

* Safety can not be guaranteed if this IC is damaged and control no longer is possible. Please protect with something other than this IC.

Measuring Circuit




Measurement Procedures


(Except where otherwise indicated $T_a = 25^\circ\text{C}$, $V_{CC} = 5\text{V}$, V_{CC} : current limit 0.5A, $V_1 = 0\text{V}$, $V_2 = V_{CC}$, $V_9 = 4.27\text{V}$, S6, 7, 8, 11, 14, 15: A)

Item	Measurement Procedure
Consumption current 1	Measure A13 current value I_{CC1} at $V_1 = 1.2\text{V}$, $V_2 = 0\text{V}$.
Consumption current 2	Measure A13 current value I_{CC2} .
Reference voltage	Measure T3 potential V_{REF} .
ADP detection voltage L	Gradually lower V_{CC} from 5V. V_{CC} potential is V_{ADPL} when T14 potential goes above $V_{CC} - 0.5\text{V}$.
ADP detection voltage L hysteresis voltage width	Gradually raise V_{CC} from 2V. V_{CC} potential is V_{ADPL2} when T14 potential goes under 0.5V. $V_{ADPLW} = V_{ADPL2} - V_{ADPL}$
ADP detection voltage H	Gradually raise V_{CC} from 5V. V_{CC} potential is V_{ADPH} when T15 potential goes above $V_{CC} - 0.5\text{V}$.
ADP detection voltage H hysteresis voltage width	Gradually lower V_{CC} from 7V. V_{CC} potential is V_{ADPH2} when T15 potential goes under 0.5V. $V_{ADPHW} = V_{ADPH} - V_{ADPH2}$.
BAT pin leak current	$V_{CC} = 0\text{V}$, $V_2 = 0\text{V}$, S11: B, $V_{11} = 0\text{V}$. Measure A9 current value I_{BAT} .
BAT pin output voltage	Gradually raise V_9 from 3.5V. T9 potential is V_{BAT} when the potential difference between T13-T12 is 20mV or less.
CNT pin output voltage	$V_9 = 3.5\text{V}$, S11: B. Gradually raise V_{11} from 0V. T11 potential is V_{CNT} when A11 current value is 20mA.
SW1 pin input current	Measure A1 current value I_{SW1} .
SW1 pin input voltage H	$V_9 = 3.5\text{V}$, $V_2 = 0\text{V}$. Raise V_1 from 0V to 1.2V. Identify V_{SW1H} or L ; when A9 is 50mA or higher, charging ON at current limit 2, and when A9 is 1mA or lower, charging is OFF.
SW1 pin input voltage L	$V_1 = 0\text{V}$, $V_2 = 2\text{V}$. Measure A2 current value I_{SW2} .
SW2 pin input current	$V_9 = 3.5\text{V}$, $V_1 = 0\text{V}$. Raise V_2 from 0V to V_{CC} . Identify V_{SW2H} or L ; when A9 is 450mA or higher, charging ON at current limit 1, and when A9 is 1mA or lower, charging is OFF.
Current limit 1	$V_1 = 0\text{V}$, $V_2 = V_{CC}$, $V_9 = 3.5\text{V}$. Gradually raise V_{CC} current limit value and measure the potential difference between T13-T12, V_{L1} .
Current limit 2	$V_1 = 1.2\text{V}$, $V_2 = 0\text{V}$, $V_9 = 2.5\text{V}$. Potential difference between T13-T12 is V_{L2} .
Current detection amp gain	$V_9 = 3.5\text{V}$. The potential difference fluctuation between T13-T12 when V_{CC} current limit value is changed from 100mA to 200mA is ΔV_a and the T6 potential fluctuation is ΔV_b . $G_1 = 20\log \Delta V_b / \Delta V_a $
Current detection amp output offset voltage	$V_9 = 4.0\text{V}$. T6 potential is V_{b2} when V_{CC} current limit is 100mA. $V_{OFF} = V_{b2}/8 - 30\text{mV}$
Current detection amp output current outflow	$V_9 = 3.5\text{V}$, V_{CC} current limit value is 300mA, S6: B, $V_6 = 0\text{V}$. Measure A6 current value.
V_{OUT1} pin output voltage	S15: B. Gradually raise V_{15} from 0V. T15 potential is V_{OUT1} when A15 current value is 0.12mA.
V_{OUT2} pin output voltage	S14: B. Gradually raise V_{14} from 0V. T14 potential is V_{OUT2} when A14 current value is 0.12mA.
Battery temperature detection voltage hysteresis voltage width	S8: B. Gradually lower V_8 from 0.6V. T8 potential is V_{TDET} when T7 potential is 0.3V or under.
Battery temperature detection voltage hysteresis voltage width	S8: B. Gradually raise V_8 from 0V. T8 potential is V_{TDET2} when T7 potential is 0.8V or higher. $V_{TDETW} = V_{TDET2} - V_{TDET}$.
T_{OUT} pin output voltage	S8: B, $V_8 = 0\text{V}$, S7: B. Gradually raise V_7 from 0V. T7 potential is V_{TOUT} when A7 current value is 0.12mA.
T_{DET} input bias current	S8: B, $V_8 = 0\text{V}$. Measure A8 potential value I_t .

Timing Chart




Application Circuits




Characteristics


■ Current Limit 1 vs Ambient temperature




■ Current Limit 2 vs Ambient temperature




■ BAT Pin Output Voltage vs Ambient temperature




■ Current Detection Input/Output



■ VCNT Voltage vs ICNT Current



■ BAT Pin Reverse Current vs BAT Pin Voltage



■ ADP Detection H Delay Time

