System Reset (with battery back-up)

Monolithic IC PST620, 621

Outline

These ICs are part of the regular series of back-up ICs, and use capacitors (super capacitor, large capacity chemical capacitor) as back-up power supply. They control 1-chip microcomputer high-speed, low-speed, and stand-by modes (MNI control).

These ICs also are capable of controlling data save in EPROM and other nonvolatile memories during power outage.

Features

- 1. Low current consumption
- Capacitors (super capacitor, large capacity chemical capacitor) are used for back-up power supply, lowering system cost
- 3. Stable 1-chip microcomputer crystal oscillator rise time maintained with the built-in pulse shaver.
- 4. In addition to power outage detection for main power supply (+5V), there are built-in pins to detect AC power supply and +5V power supply primary side
- 5. Reset signal output by back-up power supply (super capacitor, large capacity chemical capacitor) detection


Package

DIP-8B (PST620DDB, PST621DDB) SOP-8C (PST620DFT, PST621DFT)

Applications

- 1. VCR
- 2. Audio equipment
- 3. Communications equipment
- 4. Rice cookers, etc.

Pin Assignment



Pin Description


■ PST620

Pin No.	Pin name	Function			
1	VAC	Has +2.0V detection voltage to detect AC power supply and			
		stable power supply primary side, for quick power outage detecti			
2	Vcc1	+5V main power supply			
3	Vcc2	Back-up power supply (back-up capacitor connected)			
4	TC	Pulse width setting pin for pulse shaver			
		(capacitor and resistor connected)			
5	RE	Reset output			
6	PScont	Pulse shaver ON/OFF switching High: OFF Low: ON			
7	CE	Chip enable signal output			
8	GND	GND			

■ PST621

Pin No.	Pin name	Function		
1	Vac	Has +2.0V detection voltage to detect AC power supply and		
		stable power supply primary side, for quick power outage detection.		
2	Vcc1	+5V main power supply		
3	Vcc2	Back-up power supply (back-up capacitor connected)		
4	Tc	Pulse width setting pin for pulse shaver		
		(capacitor and resistor connected)		
5	RE	Reset output		
6	MODE	Switches 1-chip microcomputer mode with pulse		
		shaver output signal		
7	CE	Chip enable signal output (power outage detection signal)		
8	GND	GND		

Block Diagram



Absolute Maximum Ratings (Ta=25°C)

Item	Symbol	Rating		
Storage temperature	Tstg	-40~+125℃		
Operating temperature	Topr	−20~+70°C		
Power supply voltage	Vcc max.	-0.3~+10V		
TC input input voltage	Vc max.	Vcc1+0.3V		
Allowable loss	Pd	450mW		


Electrical Characteristics (Ta=25°C)

Item		Symbol	Measurement conditions	Min.	Тур.	Max.	Units	
Detection voltage 1		Vs1	RL1=47kΩ CE output, Vcc1=L \rightarrow H \star 1	4.00	4.20	4.40		
	ST620	- Vs2	R ₁ 2=47kΩ, RE output	2.00	2.15	2.30	-	
voltage 2			Vcc2=H →L *1	2.90	3.10	3.30	V	
Detection voltage 3		Vs3	R _L 1=47kΩ, CE output, V _{AC} = $H \rightarrow L + 1$	1.85	2.00	2.15		
Hysteresis voltage 1		⊿Vs1	RL1=47k Ω , CE output, Vcc1=L \rightarrow H \rightarrow L	75	150	300		
Hysteresis voltage 2		∠Vs2	R _L 2=47k Ω , CE output, Vcc2=L \rightarrow H \rightarrow L	25	50	100	mV	
Hysteresis voltage 3		∠Vs3	$R_L 1 = 47k\Omega CE$ output, $V_{AC} = L \rightarrow H \rightarrow L$	45	90	180		
Detection voltage		Vs/⊿T	$R_L 1=47k\Omega$, CE output		0.01			
temperature coefficient 1					±0.01			
Detection volta			R ₁ 2=47kΩ, RE output				%/°C	
temperature coeffic	~	Vs/⊿T			±0.02			
Detection volta		Vs/⊿T						
	temperature coefficient 3		R _L 1=47k Ω , CE output	No.	±0.01			
Low-level output voltage 1		Vol1	Vcc1=Vs1 min.–0.05V, Rt1=47kΩ CE output		0.1	0.2		
Low-level output vo		Vol2	Vcc2=Vs2 min0.05V, Rt2=47kzΩ RE output		0.1	0.4		
		Vol3	Vcc1=0V, Vcc2=Vs2 typ./0.85				V	
Low-level output vo	Low-level output voltage 3		$R_L 1 = 47 k\Omega$, CE output		0.2	0.4		
Operation limit voltage 1		Vop1	$R_L 1 = 47k\Omega$, $V_{OL} 1 \le 0.4V$ CE output		0.8	1.0		
	Operation limit voltage 2		$R_1 = 47k\Omega$, $V_{01} \ge 0.4V$ RE output		0.8	1.0	V	
		Vop2 Icc1	Vcc1=Vcc2=Vs1/0.85		5.0	8.5		
Consumption current 1		Icc2	Ri.1=Ri.2=∞		2.0	3.5	μΑ	
Consumption current 2		Icc1	Vcc1=Vcc2=Vs1 min0.05V		8.0	14.5		
		Icc2	R _L 1=R _L 2=∞		2.0	3.5		
		Icc1	Vcc1=Vcc2=Vs2 min0.05V		8.0	14.5		
Consumption curr	rent 3	Icc2	R1=R2=∞		4.0	7.0	-	
		Icc2 X	Vcc1=0V Rl1=Rl2=∞,			μΑ		
Consumption curr	Consumption current 4		Vcc2=Vs1T typ./0.85		2.0		3.5	
			Vcc1=0V Rl1=Rl2=∞	4.0	4.0		7.0	
Consumption curr	rent 5	Icc2	Vcc2=Vs2 min0.05V		4.0	7.0		
Output current while	le on 1	Iol1	Vcc1=Vs1 min0.05V, Rt1=0 CE output	2				
Output current while on 2		Iol2	Vcc2=Vs2 min0.05V, Rt2=0 RE output	2			mA	
Transport delay ti		Тегн1			10			
Transport delay ti	ort delay time 2		Vcc2=Vs2 typ.±0.4V, Rt2=47kΩ RE output		50			
Transport delay ti			Vcc1=Vs1 typ.±0.4V, Rt2=47kΩ CE output		40		μS	
Transport delay ti	Transport delay time 4		Vcc2=Vs2 typ.±0.4V, Rt2=47kΩ RE output		80			
AC pin input resist	stance RACIN		-	0.5	1.0		ΜΩ	
One-shot pulse w	vidth	Tpd	Cd=0.47µF Rd=100k, Vcc1=Vs1 typ.±0.4V		14	21	mS	
One-shot output ve	oltage	V _{TOL}	Vcc1=Vs1 typ./0.85, RL1=47k Ω RE output, \star 1		0.1	0.4	V	
TC pin threshold ve	oltage	VCTH	$R_L 1=47k\Omega$, $V_C=L \rightarrow H$		2.0		V	
TC input input current		Icin	Vcc1=Vs1 typ./0.85, VC=5.0V			1	μA	
PS pin input H level voltage		VPSH		2.0			V	
PS pin input L level voltage		VPSL				0.6	V	
PS pin input H level current		IPSH	V _{PSH} =2.0V			10	μA	
Note 1 : *1 Connect TC pin to			I	1			•	

Note 1: *1 Connect TC pin to GND.


Note 2 : Except where noted otherwise, VAC=5V, Vc=OPEN.

Characteristics (PST620, 621 series. However, VS2 in PST620 series only.)



Timing Chart

PST620




Note 1: VTH is set at 2.0V and hysteresis voltage at 90mV.

- 1. Use a resistor to divide the detected voltage so that it equals Virtuely monitoring regulator primary side power supply.
- 2. When monitoring AC voltage rectified as in the application circuit, set so that it equals V™ by lowering the constant and dividing with a resistor. Refer to application circuit diagram.


Note 2: VAC input and VS1 are OR, so either signal makes CE low when power outage is detected.

PST621



Application Circuits

input: Power supply transformer secondary voltage detection



D1,D2,D3 D4 Rectification diodes

Super capacitor charging, reverse current prevention shot key barrier diode

C1,C2 C3 C4 C5 Power supply capacitors Bypass capacitor Rectification capacitor Super capacitor

Ĉ6 1-shot pulse width setting capacitor VAC voltage stabilizing resistors Controls current flow

to super capacitor 1-shot pulse setting resistor Power supply transformer 3 pin regulator R4

T1 IC1

ic2 ic3 PST620

: 1-chip microcomputer

1. Connection

- 1. +5V power supply to Vcc1 (Pin 2).
- 2. Connect back-up capacitor to Vcc2 (Pin 3).
- 3. Connect a diode between Vcc1 (Pin 2) and Vcc2 (Pin 3).
- 4. Connect pulse width setting resistor and capacitor to PC (Pin 4) when using pulse shaver.
- 5. RE output (Pin 5) is reset signal output and is output when Vcc is less than 2.15V.
- 6. When using pulse shaver, PSCONT (Pin 6) is high level.
- 7. CE output (Pin 7) is for chip enable signal and goes low when power outage is detected.

2. Theory of Operation


- 1. When +5V power is supplied normally, it is charged to the back-up capacitor via a diode.
- 2. The back-up capacitor starts back-up if +5V power supply voltage drops for some reason and Vcc1 goes below 4.2V, and at the same time the CE signal switches the 1-chip microcomputer to standby mode, so that it operates on low current consumption.
- 3. When +5V power supply recovers and goes over 4.2V, an RE output signal of a certain width is output, and this signal resets the 1-chip microcomputer. At the same time normal mode starts and the time until crystal oscillator output stabilizes is reset.
- 4. If +5V power supply does not recover, and back-up capacitor voltage goes below 2.15V, reset is carried out by the RE output signal to prevent the microcomputer from running wild.

3. Setting AC power supply power outage detection

- 1. Theory of operation for detecting AC voltage AC voltage is rectified and smoothed by the capacitor. This voltage is divided and set at VAC input detection voltage, +2V. At this time the smoothing capacitor and dividing resistor time constants are used to set AC voltage missing waveform.
- 2. VAC voltage setting (R1, R2) Set resistor ratio at the midpoint between R1 and R2 so that the voltage to be detected is +2V. Impressed AC voltage There is are no limitations on AC voltage as it is divided by R1 and R2 and applied to PST620.
- Setting time constants to detect AC voltage (C4, R1+R2) For impressed AC voltage of 5Vrms, and C4 and R1+R2 time constant of 60mS, set so that AC voltage detects power outage when approximately 2 waveforms are missed. The time constants can be set to detect missing AC waveforms.

Application Circuits





D1,D2 D4 Bypass capacitor Super capacitor charging, reverse current prevention shot key barrier diode Power supply capacitors Bypass capacitor

C1,C2 C3 C4 C5 C6 Réctification capacitor

Super capacitor 1-shot pulse width setting capacitor

R1,R2: VAC voltage stabilizing resistors

Controls current flow to super capacitor 1-shot pulse setting resistor Power supply transformer 3 pin regulator PST620 R4 T1

: 1-chip microcomputer